



1) Here you can see the 3 parts to the slim tools. They are lettered A, B and C on the picture above.



3) A larger image to show the detail of Tool C. Please do not press the protrusive spare part of the tool.



5) Take the Tool A and stick it in the place on the picture above.



7) Then, please insert the Tool B in the place on the picture above.



2) Stickers are prepared behind Tool A.



4) On the picture above you can see the console front view opened. Here you can see where each tool takes its place.



6) Now its time to set the Tool B. Please move the disk break to the right and hold it.



8) On the left hand side you can see the position for Tool C. Please put Tool C in the gap. And then push it till it goes no further downwards. As a result your console is ready for playing your imports.